

RegenOx® Technical Description

RegenOx® is an advanced chemical oxidation technology that destroys contaminants through powerful, yet controlled chemical reactions. This product maximizes in situ chemical oxidation (ISCO) performance through use of a two-part product system; a sodium percarbonate oxidizer complex activated by a patented surface catalyst system. The technology degrades pollutants through direct oxidation, as well as through the generation of a suite of free radical compounds which in turn oxidize recalcitrant contaminants. RegenOX rapidly and effectively destroys a range of target contaminants including petroleum hydrocarbons and chlorinated compounds.

RegenOx is especially effective in destroying target contaminants present in high concentration source areas within the saturated and vadose zones. For petroleum hydrocarbon treatment, RegenOx produces oxygen as a result of its reactions, providing seamless transition from ISCO to enhanced aerobic bioremediation. RegenOx produces minimal heat when applied, and continues to destroy contaminants for up to 30 days on a single application. RegenOx is safe for use in direct contact with underground utilities, since it is non-corrosive to concrete and most metals.



Close up of RegenOx

$C_2Cl_4 + 4/3 Na_2CO_3 \cdot 2H_2O_2 + 4NaOH \rightarrow 2CO_2 + 4NaCl + 4H_2O + 4/3 Na_2CO_3$

Free Radical Oxidation via production of:

- Perhydroxyl Radical (HO₂ •) - Hydroxyl Radical (OH •) - Superoxide Radical (O₂ •)

For a list of treatable contaminants with the use of RegenOx, view the Range of Treatable Contaminant Guide.

Chemical Composition - Part A Oxidant

- Sodium Percarbonate CAS #15630-89-4
- Sodium Carbonate Monohydrate CAS #5968-11-6
- Silicic Acid CAS #7699-11-6
- Silica Gel CAS #63231

Chemical Composition - Part B Activator Complex

- Silicic Acid, Sodium Salt, Sodium Silicate CAS#1344-09-08
- Silica Gel CAS #63231
- Ferrous Sulfate CAS #7720-78-7
- Water CAS#7732-18-5

Properties

- Bulk Density Part A 0.9-1.2 g/cm³; Part B 1.39 g/cm³
- pH 10-11 per recommended mixing ratios (3-5% oxidant in solution)
- Solubility Oxidant 14.5 g/100 g water; Activator miscible in water
- Appearance Brown to orange-brown when mixed with water
- Odor Not detectable
- Vapor Pressure None
- Non-hazardous

 1/2



RegenOx® Technical Description

Storage and Handling Guidelines

Storage
Store in a cool, dry place out of heat/direct sunlight
Store at temperatures not to exceed 40°C/104°F
Store in original tightly closed container
Store in a well-ventilated place
Do not store near combustible materials
Store away from incompatible materials
Protect from contamination
Provide appropriate exhaust ventilation in places where dust is formed

Handling
Minimize dust generation and accumulation
Observe good industrial hygiene practices
Keep away from clothing and combustible materials
Take any precaution to avoid mixing with combustibles
Avoid contact with eyes
Do not taste or swallow
Do not eat, drink or smoke nearby
Wear appropriate personal protective equipment
Wash hands thoroughly after handling
Avoid release to the environment

Applications

RegenOx is applied using direct-injection techniques or wells. The application process enables the two- part product to be combined, then pressure-injected into the zone of contamination and moved out into the aquifer media. Application instructions for this product are contained in the RegenOx- Application Instructions Guide.

Health and Safety

Material is relatively safe to handle; however, we recommend avoiding contact with eyes, skin and clothing. OSHA Level D personal protection equipment including vinyl or rubber gloves, eye protection and dust mask are recommended when handling this product. Please review the Material Safety Data Sheet for additional storage, packaging, usage, and handling requirements here: RegenOx Part A SDS and RegenOx Part B SDS.



www.regenesis.com Corporate Headquarters 1011 Calle Sombra, San Clemente CA 92673 949.366.8000

Cambridge House, Henry Street, Bath BA1 1BT, United Kingdom europe@regenesis.com